

# SXE-SSE **DN 65÷100**

The Easyfit check valve line developed with Giugiaro Design offers two different versions: SXE with ball shutter and SSE with spring loaded shutter. Easyfit check valves stand out for the innovative installation method that guarantees reliable service over time.


This valve is also equipped with a customisable Labelling System.



## EASYFIT TRUE UNION BALL AND SPRING CHECK VALVE

- Connection system for solvent weld and threaded joints
- Valve material compatibility (PVC-U) with water, drinking water and other food substance conveyance according to current regulations
- PN16 True Union valve body made for PVC-U injection moulding and compliant with European Directive 97/23/EC for PED pressurised equipment. Test requirements compliant with ISO 9393
- Easy radial dismounting and fully interchangeable with VEE and VXE 65-100 valve models
- Union nut profile that perfectly adapts to the Easyfit multifunctional handle hooked insert (available as an accessory) that lets you control union nut rotation
- Vertical (preferable for SXE model) and horizontal installation potential

Technical specifications	
Construction	SXE: Easyfit True Union ball check valve with locked carrier SXE: Easyfit True Union spring check valve with locked carrier
Size range	DN 65 ÷ 100
Nominal pressure	PN 16 with water at 20 °C
Temperature range	0 °C ÷ 60 °C
Coupling standards	Solvent welding: EN ISO 1452, EN ISO 15493, BS 4346-1, DIN 8063, NF T54-028, ASTM D 2467, JIS K 6743. Pipe coupling capacity according to EN ISO 1452, EN ISO 15493, DIN 8062, NF T54-016, ASTM D 1785, JIS K 6741  Thread: ISO 228-1, DIN 2999, ASTM D 2464, JIS B 0203
Reference standards	Construction criteria: EN ISO 16137, EN ISO 1452, EN ISO 15493
	Test methods and requirements: ISO 9393
	Installation criteria: DVS 2204, DVS 2221, UNI 11242
Valve material	PVC-U
Seal material	EPDM, FPM (standard size O-Ring)
Spring material (SSE)	Available in STAINLESS Steel 316, A316 PTFE encapsulated




- Customisable Labelling
  System: built-in LCE module
  on the valve body made up of
  transparent protection plug
  and customisable tag holder
  using the LSE set (available as
  accessory). The customisation
  potential lets you identify the
  valve on the system according
  to specific needs
- 2 Optimised dynamic fluid design: energy savings due to the improved valve Kv value and consequent reduced pressure drop
- 3 High surface finish ball shutter: reduced wear, longer working life and reduced valve maintenance. Ideal to convey dirty fluids, even with suspended fluids or filaments, thanks to the special design that permits internal valve self-cleaning
- 4 Locked ball seat carrier: safe dismounting for maintenance with the Easyfit multifunctional handle
- 5 Ideal for horizontal installations: perfect seal even with low back pressure.
  - **Silent** and durable even with strong vibrations and pulsating fluid
- 6 PVC-U shutter and springs available in STAINLESS Steel 316, A316 PTFE encapsulated: maximum reliability in a wide field of applications from salt water to aggressive acids

## TECHNICAL DATA


# PRESSURE VARIATION ACCORDING TO TEMPERATURE

For water and harmless fluids to which the material is classified as CHEMICALLY RESISTANT. In other cases, a reduction of the nominal PN pressure is required (25 years with safety factor).



Working temperature

## PRESSURE DROP GRAPH



Flow Rate

# K<sub>V</sub>100 FLOW COEFFICIENT

The  $\rm K_v 100$  flow coefficient is the Q flow rate of litres per minute of water at a temperature of 20°C that will generate  $\Delta p = 1$  bar pressure drop at a certain valve position.

The  $K_v$ 100 values shown in the table are calculated with the SXE valve completely open.

DN	65	80	100
K <sub>v</sub> 100 l/min	2586	3444	5093

### MINIMUM VALVE SEALING PRESSURE

DN	65	80	100
SXE (bar)	0.2	0.2	0.2
SSE (bar)	0.08	0.08	0.08

The PVC-U SXE valve can only be used with liquids with specific weight under 1,37g/cm<sup>3</sup>.

The information in this leaflet is provided in good faith. No liability will be accepted concerning technical data that is not directly covered by recognised international standards. FIP reserves the right to carry out any modification. Products must be installed and maintained by qualified personnel.

## DIMENSIONS



#### **SXEIV**

Easyfit ball check valve with female ends for solvent welding, metric series

d	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
75	65	16	157	211	44	123	2605	SXEIV075E	SXEIV075F
90	80	16	174	248	51	146	3300	SXEIV090E	SXEIV090F
110	100	16	212	283	61	161	5770	SXEIV110E	SXEIV110F



#### **SXEFV**

Easyfit ball check valve with BSP threaded female ends


R	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	30.2	150.6	2605	SXEFV212E	SXEFV212F
3"	80	16	174	248	33.3	181.4	3300	SXEFV300E	SXEFV300F
4"	100	16	212	283	39.3	204.4	5770	SXEFV400E	SXEFV400F



#### SXFLV

Easyfit ball check valve with female ends for solvent welding, BS series

d	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	44	123	2605	SXELV212E	SXELV212F
3"	80	16	174	248	51	146	3300	SXELV300E	SXELV300F
4"	100	16	212	283	63	157	5770	SXELV400E	SXELV400F



#### SXEAV

Easyfit ball check valve with female ends for solvent welding, ASTM series

d	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	44.5	122	2605	SXEAV212E	SXEAV212F
3"	80	16	174	248	48	152	3300	SXEAV300E	SXEAV300F
4"	100	16	212	283	57.5	168	5770	SXEAV400E	SXEAV400F



#### **SXFNV**

Easyfit ball check valve with female ends, NPT thread

R	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	33.2	144.6	2605	SXENV212E	SXENV212F
3"	80	16	174	248	35.5	177	3300	SXENV300E	SXENV300F
4"	100	16	212	283	37.6	207.8	5770	SXENV400E	SXENV400F



#### SXEJV

Easyfit ball check valve with female ends for solvent welding, JIS series


d	DN	PN	E	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	243	61	121	2605	SXEJV212E	SXEJV212F
3"	80	16	174	272	64.5	143	3300	SXEJV300E	SXEJV300F
4"	100	16	212	332	84	164	5770	SXEJV400E	SXEJV400F



#### **SXEGV**

Easyfit ball check valve with female ends, JIS thread

R	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	35	141	2605	SXEGV212E	SXEGV212F
3"	80	16	174	248	40	168	3300	SXEGV300E	SXEGV300F
4"	100	16	212	283	45	193	5770	SXEGV400E	SXEGV400F



#### **SXFRFV**

Easyfit ball check valve with PE100 SDR 11 male end connectors for butt welding or electrofusion (CVDE)


d	DN	E	Н	L	Z	g	EPDM Code	FPM Code
75	65	157	331	71	189	2605	SXEBEV075E	SXEBEV075F
90	80	174	367	88	191	3300	SXEBEV090E	SXEBEV090F
110	100	212	407	92	223	5770	SXFBFV110F	SXFBFV110F



#### SSEIV

Easyfit spring check valve with female ends for solvent welding, metric series

d	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
75	65	16	157	211	44	123	2480	SSEIV075E	SSEIV075F
90	80	16	174	248	51	146	3090	SSEIV090E	SSEIV090F
110	100	16	212	283	61	161	5370	SSEIV110E	SSEIV110F



#### **SSEFV**

Easyfit spring check valve with BSP threaded female ends  $\,$ 

F	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	30.2	150.6	2480	SSEFV212E	SSEFV212F
3	80	16	174	248	33.3	181.4	3090	SSEFV300E	SSEFV300F
4	100	16	212	283	39.3	204.4	5370	SSEFV400E	SSEFV400F



#### **SSELV**

Easyfit spring check valve with female ends for solvent welding, BS series

d	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	44	123	2480	SSELV212E	SSELV212F
3"	80	16	174	248	51	146	3090	SSELV300E	SSELV300F
4"	100	16	212	283	63	157	5370	SSELV400E	SSELV400F



#### **SSEAV**

Easyfit spring check valve with female ends for solvent welding, ASTM series

d	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	44.5	122	2480	SSEAV212E	SSEAV212F
3"	80	16	174	248	48	152	3090	SSEAV300E	SSEAV300F
4"	100	16	212	283	57.5	168	5370	SSEAV400E	SSEAV400F



### **SSENV**

Easyfit spring check valve with female ends, NPT thread

R	DN	PN	E	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	33.2	144.6	2480	SSENV212E	SSENV212F
3"	80	16	174	248	35.5	177	3090	SSENV300E	SSENV300F
4"	100	16	212	283	37.6	207.8	5370	SSENV400E	SSENV400F



### **SSEJV**

Easyfit spring check valve with female ends for solvent welding, JIS series

d	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	243	61	121	2480	SSEJV212E	SSEJV212F
3"	80	16	174	272	64.5	143	3090	SSEJV300E	SSEJV300F
4"	100	16	212	332	84	164	5370	SSEJV400E	SSEJV400F



#### **SSEGV**

Easyfit spring check valve with female ends, JIS thread

R	DN	PN	Е	Н	L	Z	g	EPDM Code	FPM Code
2" 1/2	65	16	157	211	35	141	2480	SSEGV212E	SSEGV212F
3"	80	16	174	248	40	168	3090	SSEGV300E	SSEGV300F
4"	100	16	212	283	45	193	5370	SSEGV400E	SSEGV400F
	1	1				1	ı	1	ı



#### **SSEBEV**

Easyfit spring check valve with PE100 SDR 11 male end connectors for butt welding or electrofusion (CVDE)  $\,$ 

d	DN	Е	Н	L	Z	g	EPDM Code	FPM Code
75	65	157	331	71	189	2480	SSEBEV075E	SSEBEV075F
90	80	174	367	88	191	3090	SSEBEV090E	SSEBEV090F
110	100	212	407	92	223	5370	SSEBEV110E	SSEBEV110F

## **ACCESSORIES**



#### **CVDE**

Long spigot PE100 end connectors for joints with electrofusion fittings or for butt welding

d	DN	PN	L	SDR	Code
75	65	16	111	11	CVDE11075
90	80	16	118	11	CVDE11090VXE
110	100	16	127	11	CVDE11110VXE



#### **EASYFIT HANDLE DN 65÷100**

Easyfit multifunctional handle for union nut tightening SXE-SSE DN 65÷100

d	DN	Code
75	65	HSVXE075
90	80	HSVXE090
110	100	HSVXE110



#### **LSE**

Customisation set and label printing for Easyfit handle made up of precut adhesive sheets and software for guided label creation.

d	DN	Code
75	65	LSE063
90	80	LSE063
110	100	LSE063

## CUSTOMISATION

SXE and SSE DN 65÷100 Easyfit valves are equipped with a customisable Labelling System.

This system lets you create special labels to affix to the valve body. This makes it extremely easy to apply company logos, identification serial numbers or service indications such as, for example, the valve function in the system, the transported fluid, but also specific information for customer service, such as the customer name or installation date or location on the valves.

The specific LCE module is a standard supply and is made up of a rigid transparent water-resistant PVC plug and white tag holder made of the same material, one side of which bears the FIP logo.

The holder, inserted in the plug, can be removed and, once overturned, used for customisation by applying labels printed with the software supplied with the LSE set.


Proceed as follows to apply the label on the valve:


- 1) Remove the transparent plug from the housing on the valve body.
- 2) Extract the tag holder from the transparent plug.
- Apply the adhesive label on the holder to align the profiles matching the tab position.
- 4) Reinsert the tag holder in the transparent plug so that the label is protected against the elements.
- 5) Replace the transparent plug in its seat on the valve body.



## COMPONENTS

## **EXPLODED VIEW**





- 1 · Union nut (PVC-U 2)
- 2 · End connector (PVC-U 2)
- 3 · Socket seal O-Ring (EPDM, FPM - 2)
- 4 · Body (PVC-U 1)
- 5 · Tag holder (PVC 1)

- 6 · Transparent protection plug (PVC - 1)
- 7 SXE · Ball (PVC-U 1)
- **7 SSE** · Shutter (PVC-U 1)
- 8 · Gland packing ring (PVC-U 1)
- 9 SXE · Ball seat O-Ring (EPDM, FPM - 1)
- 9 SSE · Shutter seat O-ring (EPDM, FPM - 1)
- 10 SXE · Ball seat carrier (PVC-U 1)
- 10 SSE · Shutter seat carrier
- 11 · Radial seal O-Ring (EPDM, FPM - 1)
- 12 · Spring (STAINLESS steel\* 1)

The component material and quantity supplied are indicated in the parentheses.

<sup>\*</sup> Also available made of A316 PTFE encapsulated

#### DISMOUNTING

SXE valves do not require maintenance in normal operating conditions. In the event of leaks or wear, before performing maintenance, cut-off fluid upstream from the valve and make sure it is depressurised (downstream drain if necessary).

- 1) Fully drain residual liquid that could be aggressive for the operator and, if possible, circulate water to internally clean the valve.
- 2) For easy union nut tightening in assembly, use the Easyfit multifunctional handle (supplied as an accessory).
- 3) Unscrew the ball seat carrier (10) with the Easyfit multifunctional handle: introduce the two protrusion on the top of the handle in the grooves in the carrier (10) and unscrew, extracting it counter-clockwise.
- 4) Remove all internal components.

In the event of leaks or wear, before performing maintenance, cut-off fluid upstream from the valve and make sure it is de-pressurised (downstream drain if necessary).

- 1) Fully drain residual liquid that could be aggressive for the operator and, if possible, circulate water to internally clean the valve.
- 2) For easy union nut tightening in assembly, use the Easyfit multifunctional handle (supplied as an accessory).
- 3) Unscrew the ball seat carrier (10) with the Easyfit multifunctional handle: introduce the two protrusion on the top of the handle in the grooves in the carrier (10) and unscrew, extracting it counter-clockwise.
- 4) Remove all internal components.

#### **ASSEMBLY**

- 1) Reconstruct the valve following the exploded view on the previous page.
- 2) Tighten the ball seat carrier (10) using the Easyfit multifunctional handle. This ensures optimal valve installation and operations (fig. 3).
- 3) Position the valve between the end connectors (2) and tighten the union nuts clockwise (1) using the Easyfit multifunctional handle (fig. 7) being sure the socket seal O-ring (3) does not exit the seats.

#### SSE

- 1) Reconstruct the valve following the exploded view on the previous page.
- 2) Tighten the ball seat carrier (10) using the Easyfit multifunctional handle. This ensures optimal valve installation and operations (fig. 3).
- 3) Position the valve between the end connectors (2) and tighten the union nuts clockwise (1) using the Easyfit multifunctional handle (fig. 7) being sure the socket seal O-ring (3) does not exit the seats.



Note: during assembly operations, it is advisable to lubricate the rubber seals. Mineral oils are not recommended for this task as they react aggressively with EPDM rubber.









Fig. 4



## INSTALL ATION

SXE and SSE valves can be installed both vertically (upward flow) and horizontally (SXE with minimum 0.2 bar back pressure).

Before proceeding with installation. please follow these instructions carefully:

- 1) Check that the pipes to be connected to the valve are aligned in order to avoid mechanical stress on the threaded joints.
- 2) Unscrew the union nuts (1) from the body (4) and insert them in the pipe segments.
- 3) Solvent weld or screw the end connectors (2) onto the pipe segments.
- 4) Position the valve body between the end connectors (fig. 1).
- 5) Place the union nuts on the valve body and start tightening manually clockwise until they are hard to turn. Do not use wrenches or other tools that can damage the union nut surface (fig. 2).
- 6) For easy union nut tightening in assembly, use the Easyfit multifunctional handle (supplied as an accessory).
- 7) Extract the hooked insert in the handle (fig. 5) overturn it and fit it in the seat on the lower part of the handle (fig. 6).
- 8) Fit the tool on the external union nut profile until firmly and safely secured that allows for adequate torque without damaging the union nut in any way (fig. 7).
- 9) Repeat point 7 for the other union nut.
- 10) When tightened, remove the hooked insert and replace it in its seat in the handle.
- 11) If necessary, support the pipe with FIP pipe clip model ZIKM and DSM distance plates.

## WARNINGS

- Do not use compressed air or other gases to test thermoplastic lines.
- Always avoid sudden closing manoeuvres and protect the valve against accidental manoeuvres.








Fig. 7



Fig. 8









Loc. Pian di Parata, 16015 Casella Genova Italy Tel. +39 010 9621.1 Fax +39 010 9621.209 info.fip@aliaxis.com



